



## STEVENSONS STONE® INSTALLATION GUIDE

---

### **For fixing into a solid flat wall:**

- Stevenson's will cast 4 to 5 stainless steel fixing points into the back of your Fire Surround
- The fixing point will consist of a BigHead fixing with 8mm stainless steel threaded rod
- The threaded rod can be cut back to the required length
- Drill fixing holes into the wall to receive the threaded rod
- Stevenson's will supply SikaFlex to be put into the fixing holes to bond to the threaded rod

**Detailed fixing instructions will be provided with your delivery.**

Alternative fixing methods are available.

Please speak to a member of our sales team if you have specific requirements with regards to fixing your Stevenson's Fireplace Surround

**Telephone:** 00 44 (0)1603 400824

**Email:** [info@stevensonsofnorwich.com](mailto:info@stevensonsofnorwich.com)